



Instructions for Kenco Forklift adapter:

1. Center forks on bulkhead at the required spacing for the adapter.
2. Place forks through tubes of adapter and slide as close as possible to bulkhead. (Fork lift adapter may be used with lift eye at either end, clearance permitting.) See Illustration Below.
3. Once adapter is on forks attach safety chains, lanyards, or straps to the attachment rings on the adapter. Provide no slack in safety attachment, be certain that attachment cannot slide off of forks.
4. Before use: ensure that all safety devices are in place, do not over exceed rated capacities of forklift, adapter, safety attachment, or barrier lifter.
5. When in use, keep forks with slight rearward tilt to avoid sliding of adapter on forks.
6. Avoid Jarring, swinging, and otherwise unnecessary manipulation of the load.
7. **Do not** use the system to pick loads off center, drag barrier wall, pick or grab non-uniform surfaces, or move items other than barrier wall that is within the specified capacities of the barrier lifter.
8. Observe all safety practices associated with forklift and crane operation.

